
shopforshops.com


Wall attachment brackets





CAUTION:

 Walls are constructed from different materials, for example, masonry or plasterboard and timber lined cavity walls (hollow). It is important that you use the appropriate wall fixings for your wall type.



Securing the Pigeonhole Unit M5050



WARNING

This product should be anchored to a wall or other suitable surface to avoid serious injury.

This product has anchor brackets provided to prevent toppling.

It is strongly recommended that you securely attach this product to a wall or other solid surface, using the anchor brackets provided and appropriate fixings.

Wall fixing devices are not included because different surface materials require different attachments.

Please seek professional advice if you are in doubt about what fixing device to use.

TO ANCHOR USE EITHER:

- The wall attachment brackets
 For use when unit is positioned against a wall.
- The two unit joining attachment brackets
 For use when two units are positioned back-to-back.

DO NOT POSITION A SINGLE UNIT IN THE MIDDLE OF A FLOOR AREA

IMPORTANT:

Regularly check that anchors are securely maintained.

Stability of tall items may be affected by thick pile carpet or uneven floors.

CAUTION:

For your safety when attaching the anchor fixings, please note the following:

- Check for any electrical wires or plumbing inside the wall before drilling any holes (if you are unsure please seek professional advice from a qualified tradesperson).
- Walls are constructed from different materials, for example, masonry or plasterboard and timber lined cavity walls (hollow). It is important that you use the appropriate wall fixings for your wall type.
- Your local hardware store will have the necessary drills and fixings and can offer advice if needed. If in doubt, engage the services of a qualified tradesperson to install and anchor the product.

